Cleaning the water sensor probes

Regular cleaning of the probes is recommended to ensure that the door seals and unseals properly. Soap, shampoo and dirt deposits can affect the proper functioning of the probes and distort the reading of the water sensor, which will cause a delay in opening the door after emptying the water.

1. Lower the door to its lowest level.



3. Using a damp microfiber cloth, clean the two sensors to prevent the accumulation of dirt, or soap or shampoo deposits.



After-sales service
1-844-4NO-STEP | 1-844-466-7837
sav@collectionassisto.com

2. Locate the two probes (LS3). They are on the same side as the backrest, at the base of the doorframe.

